

Waterproofing works subject to negative hydraulic forces

[E2]_LV11_SA_EN_R3-1121

APPLICATION DATA SHEET

Waterproofing works subject to negative hydraulic forces prior:

1. preparation of the substrate:

2. waterproofing.

1) PREPARATION OF THE SUBSTRATE

Refer to the Application Data Sheet "Preparation of substrates to be waterproofed" (LV80) for what concerns the cleaning of the substrate; preliminary controls; preparation of the substrate; and control and restoration of joints and connecting gutters.

In particular, we recommend that you:

- verify the presence of sealing elements in correspondence with connecting and fractioning joints;
- eliminate any obstacles (walls, metal guides, etc.) that could prevent the continuity of the waterproofing coating;
- create connecting gutters, collection and evacuation systems in correspondence with water coming-in points (to be treated after the creation, at the exit point of water, of a dovetail opening and its subsequent closure with **Betonfix WW**);
- apply mortar **Betonfix WW** directly on the surface in the case of widespread exudation on the surface.

2) WATERPROOFING

On the surface to be waterproofed, clean, sound and wet, lay mesh **Kimitech 350**, overlapping the sheets for a 10 cm length.

Soak the mesh by applying, with a trowel, mortar **Betonfix 300**, mixed with 35% by weight of **Kimitech ELASTOFIX** with a mortar consumption of about 1,5 kg/m².

In order to prepare the mixture, stir the product for about 5 minutes with a cement mixer or, in case of small quantities, with drill and whisk. Add 3/4 of **Kimitech ELASTOFIX** and then, gradually, the remaining product until you get the right consistency.

Once obtained a homogeneous mixture free of lumps, make it rest for 10 minutes.

Once the first layer has cured, not before 24 hours have

passed, apply with a trowel a second layer of mortar **Betonfix 300** mixed with 35% by weight of **Kimitech ELASTOFIX** with a mortar consumption of about 2 kg/m².